



MikroTik™ V2.0 Router Software Technical Reference Manual

Manual's Revision 2000-05-05

© Mikrotiks SIA 1999

Mikrotikls SIA

No part of this document may be reproduced or transmitted in any means, electronic or mechanical, for any purpose, without the written permission of Mikrotikls. Information in this document is subject to change without notice. Mikrotikls makes no representation or warranties with respect to the contents of this manual and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose.

© 1999 Mikrotikls SIA.
All rights reserved.

Printed in Latvia

MikroTik™ and Mikrotikls are trademarks of Mikrotikls SIA, Riga, Latvia.

Other trademarks used are properties of their respective owners.

Portions of this software may fall under the following copyrights:

Copyright © 1991 D.L.S. Associates

GateDaemon - Copyright © 1995, 1996, 1997, 1998 The Regents of the University of Michigan. All rights reserved. GateDaemon was originated and developed through release 3.0 by Cornell University and its collaborators.

Id.so - Copyright © 1988 Regents of the University of California. All rights reserved. Id.so software was developed by the University of California, Berkeley

cmu snmp - Copyright © 1988, 1989, by Carnegie Mellon University. All rights reserved. Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is granted, provided that the above copyright notice appear in all copies and that copyright notice and this permission notice appear in the supporting documentation.

PPP - Copyright © 1993 The Australian National University

netkit, telnet - Copyright © 1983, 1991 The Regents of the University of California. This product includes software developed by the University of California, Berkeley and its contributors. This software is provided by the regents and contributors "as is" and any express or implied warranties, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose are disclaimed.

bash, boa, dialog, e2fsprogs, fileutils, getty_ps, gzip, modutils, mount, net-tools, procps, shellutils, sysklogd, sysvinit, tar, textutils, updated, util-linux - For the above GPL licensed programs in accordance with the GPL license, Mikrotikls offers to organize a copy of the source code or it can be found on most standard Linux distributions. Write support@mikrotik.com for more information.

glibc, libstdc++, ncurses, termcap - For the above LGPL licensed programs in accordance with the LGPL license, Mikrotikls offers to organize a copy of the source code or it can be found on most standard Linux distributions. Write support@mikrotik.com for more information.

TABLE OF CONTENTS

| | |
|---|------------------|
| <u>PREFACE.....</u> | <u>7</u> |
| DOCUMENT ORGANIZATION | 7 |
| DOCUMENT CONVENTIONS | 7 |
| <u>1. STARTUP GUIDE</u> | <u>8</u> |
| 1-1 BEFORE YOU START | 8 |
| 1-2 HARDWARE REQUIREMENTS AND BIOS SETTINGS | 8 |
| 1-3 INSTALLING THE SOFTWARE | 9 |
| 1-4 CONFIGURING THE ROUTER..... | 10 |
| <u>2 USER INTERCONNECTION DESCRIPTION</u> | <u>12</u> |
| 2.1 JAVA INTERCONNECTION DESCRIPTION | 12 |
| 2.1-1 GENERAL INFORMATION | 12 |
| 2.1-2 HOW TO | 12 |
| 2.2 CONSOLE INTERCONNECTION DESCRIPTION | 14 |
| 2.2-1 HOW TO | 15 |
| 2.2-2 IMPORT AND EXPORT | 16 |
| <u>3 DEVICE DRIVER MANAGEMENT.....</u> | <u>17</u> |
| 3-1 MANAGING DEVICE DRIVERS FROM JAVA..... | 17 |
| 3-2 MANAGING DEVICE DRIVERS FROM CONSOLE..... | 17 |
| 3-3 DEVICE DRIVER PARAMETERS..... | 17 |
| 3-4 SUPPORTED INTERFACES..... | 18 |
| <u>4 NETWORK INTERFACE MANAGEMENT.....</u> | <u>21</u> |
| 4.1 INTRODUCTION..... | 21 |
| 4.1-1 MANAGING NETWORK INTERFACES FROM JAVA | 21 |
| 4.1-2 MANAGING NETWORK INTERFACES FROM CONSOLE..... | 21 |
| 4.1-3 BASIC INTERFACE PARAMETER DESCRIPTION | 22 |
| 4.2 ETHERNET INTERFACES | 22 |
| 4.2-1 MANAGING ETHERNET INTERFACES FROM JAVA | 22 |
| 4.2-2 MANAGING ETHERNET INTERFACES FROM CONSOLE | 22 |
| 4.3 ARLAN IC2200 INTERFACES | 23 |
| 4.3-1 MANAGING ARLAN IC2200 INTERFACES FROM JAVA..... | 23 |
| 4.3-2 MANAGING ARLAN IC2200 INTERFACES FROM CONSOLE | 23 |
| 4.3-3 ARLAN IC2200 PARAMETER DESCRIPTION..... | 23 |
| 4.4 LMC SYNC INTERFACES | 24 |
| 4.4-1 MANAGING LMC SYNC INTERFACES FROM JAVA..... | 24 |
| 4.4-2 MANAGING LMC SYNC INTERFACES FROM CONSOLE..... | 24 |
| 4.4-3 LMC SYNC INTERFACE PARAMETER DESCRIPTION | 24 |
| 4.5 PPP INTERFACES..... | 25 |

| | | |
|-------------|---|------------------|
| 4.5-1 | MANAGING PPP INTERFACES FROM JAVA | 25 |
| 4.5-2 | MANAGING PPP INTERFACES FROM CONSOLE | 25 |
| 4.5-3 | PPP INTERFACE PARAMETERS | 26 |
| 4.6 | IPSEC TUNNELS..... | 26 |
| 4.6-1 | MANAGING IPSEC TUNNELS FROM JAVA | 26 |
| 4.6-2 | MANAGING IPSEC TUNNELS FROM CONSOLE..... | 27 |
| 4.6-3 | IPSEC TUNNEL PARAMETERS..... | 27 |
| 4.7 | RADIOLAN INTERFACES..... | 28 |
| 4.7-1 | MANAGING RADIOLAN INTERFACES FROM JAVA | 28 |
| 4.7-2 | MANAGING RADIOLAN INTERFACES FROM CONSOLE | 28 |
| 4.7-3 | RADIOLAN INTERFACE PARAMETERS | 29 |
| 4.8 | MOXA SYNC INTERFACES..... | 29 |
| 4.8-1 | MANAGING MOXA SYNC INTERFACES FROM JAVA | 29 |
| 4.8-2 | MANAGING MOXA SYNC INTERFACES FROM CONSOLE | 29 |
| 4.8-3 | MOXA SYNC INTERFACE PARAMETERS | 30 |
| 4.9 | AIRONET 35/45/4800 INTERFACES | 30 |
| 4.9-1 | MANAGING AIRONET 35/45/4800 INTERFACES FROM JAVA | 31 |
| 4.9-2 | MANAGING AIRONET 35/45/4800 INTERFACES FROM CONSOLE | 31 |
| 4.9-3 | AIRONET 35/45/4800 INTERFACE PARAMETERS | 32 |
| 4.10 | WAVELAN INTERFACES BASE CONFIGURATION..... | 32 |
| 4.10-1 | MANAGING WAVELAN INTERFACES FROM CONSOLE | 33 |
| 4.10-2 | WAVELAN INTERFACE PARAMETERS | 33 |
| 5 | <u>BRIDGE CONFIGURATION.....</u> | <u>34</u> |
| 5-1 | CONFIGURING BRIDGE FROM JAVA | 34 |
| 5-2 | CONFIGURING BRIDGE FROM CONSOLE | 34 |
| 5-3 | BRIDGE CONFIGURATION PARAMETERS..... | 34 |
| 6 | <u>INTERNET PROTOCOL MANAGEMENT.....</u> | <u>35</u> |
| 6.1 | ADDRESSES | 35 |
| 6.1-1 | MANAGING ADDRESSES FROM JAVA | 35 |
| 6.1-2 | MANAGING ADDRESSES FROM CONSOLE | 35 |
| 6.1-3 | GENERAL ADDRESS PARAMETERS | 36 |
| 6.2 | ROUTES..... | 36 |
| 6.2-1 | MANAGING ROUTES FROM JAVA..... | 36 |
| 6.2-2 | MANAGING ROUTES FROM CONSOLE | 36 |
| 6.2-3 | GENERAL ROUTES PARAMETERS | 37 |
| 6.3 | ARP | 37 |
| 6.3-1 | MANAGING ARP FROM JAVA..... | 37 |
| 6.3-2 | MANAGING ARP FROM CONSOLE | 37 |
| 6.3-3 | GENERAL ARP PARAMETERS | 38 |
| 6.4 | PPP | 38 |
| 6.4-1 | MANAGING PPP FROM JAVA..... | 38 |
| 6.4-2 | MANAGING PPP FROM CONSOLE | 38 |
| 6.4-3 | GENERAL PPP PARAMETERS..... | 39 |
| 6.5 | DHCP | 39 |
| 6.5-1 | MANAGING DHCP FROM JAVA | 40 |
| 6.5-2 | MANAGING DHCP FROM CONSOLE | 40 |
| 6.5-3 | GENERAL DHCP PARAMETERS..... | 40 |
| 6.6 | FIREWALL..... | 41 |
| 6.6-1 | MANAGING FIREWALL FUNCTIONS FROM JAVA..... | 42 |
| 6.6-2 | MANAGING FIREWALL FUNCTIONS FROM CONSOLE..... | 42 |

| | | |
|-------------|--|-----------|
| 6.6-3 | GENERAL FIREWALL PARAMETERS | 43 |
| 6.7 | NAT | 44 |
| 6.7-1 | MANAGING NAT FROM JAVA | 44 |
| 6.7-2 | MANAGING NAT FROM CONSOLE | 45 |
| 6.7-3 | GENERAL NAT PARAMETERS | 45 |
| 6.8 | DNS | 46 |
| 6.8-1 | MANAGING DNS FROM JAVA | 46 |
| 6.8-2 | MANAGING DNS FROM CONSOLE | 46 |
| 6.8-3 | GENERAL DNS PARAMETERS | 47 |
| 7 | SNMP SERVICE CONFIGURATION | 48 |
| 7-1 | CONFIGURING SNMP FROM JAVA | 48 |
| 7-2 | CONFIGURING SNMP FROM CONSOLE | 48 |
| 7-3 | SNMP CONFIGURATION PARAMETERS | 48 |
| 8 | QUEUES MANAGEMENT | 49 |
| 8-1 | MANAGING QUEUING FROM JAVA | 49 |
| 8-2 | MANAGING QUEUING FROM CONSOLE | 49 |
| 8-3 | GENERAL QUEUING PARAMETERS | 49 |
| 9 | ADVANCED ROUTING MANAGEMENT | 52 |
| 9.1 | ROUTING INFORMATION PROTOCOL | 52 |
| 9.1-1 | MANAGING RIP FROM JAVA | 52 |
| 9.1-2 | MANAGING RIP FROM CONSOLE | 52 |
| 9.1-3 | GENERAL RIP PARAMETERS | 53 |
| 9.2 | OPEN SHORTEST PATH FIRST | 53 |
| 9.2-1 | MANAGING OSPF FROM JAVA | 53 |
| 9.2-2 | MANAGING OSPF FROM CONSOLE | 53 |
| 9.2-3 | GENERAL OSPF PARAMETERS | 55 |
| 10 | SYSTEM CONFIGURATION | 57 |
| 10.1 | TERMINAL SETUP AND BASIC SYSTEM SETUP | 57 |
| 10.1-1 | BASIC SYSTEM SETUP | 57 |
| 10.1-2 | BASIC ROUTER SETUP | 57 |
| 10.1-3 | SET TERMINAL TYPE | 58 |
| 10.2 | PACKAGES | 58 |
| 10.2-1 | VIEWING PACKAGES FROM JAVA | 58 |
| 10.2-2 | VIEWING PACKAGES FROM CONSOLE | 59 |
| 10.2-3 | PACKAGES PARAMETERS | 59 |
| 10.3 | SYSTEM HISTORY | 60 |
| 10.3-1 | VIEWING SYSTEM HISTORY FROM JAVA | 60 |
| 10.3-2 | VIEWING SYSTEM HISTORY FROM CONSOLE | 60 |
| 10.3-3 | SYSTEM HISTORY PARAMETERS | 60 |
| 10.4 | USER MANAGEMENT | 60 |
| 10.4-1 | USER MANAGEMENT FROM JAVA | 60 |
| 10.4-2 | USER MANAGEMENT FROM CONSOLE | 61 |
| 10.4-3 | USER PARAMETERS | 61 |
| 10.5 | CHANGE PASSWORD | 62 |

| | | |
|--------------|--|-----------|
| 10.5-1 | HOW TO CHANGE PASSWORD USING JAVA | 62 |
| 10.5-2 | HOW TO CHANGE PASSWORD USING CONSOLE..... | 62 |
| 10.6 | SYSTEM RESOURCES..... | 63 |
| 10.6-1 | VIEWING SYSTEM RESOURCES FROM JAVA | 63 |
| 10.6-2 | VIEWING SYSTEM RESOURCES FROM CONSOLE..... | 63 |
| 10.6-3 | SYSTEM RESOURCES PARAMETERS | 63 |
| 10.7 | SYSTEM SHUTDOWN | 64 |
| 10.7-1 | SYSTEM SHUTDOWN FROM JAVA..... | 64 |
| 10.7-2 | SYSTEM SHUTDOWN FROM CONSOLE..... | 64 |
| 10.8 | SYSTEM IDENTITY..... | 65 |
| 10.8-1 | SETTING SYSTEM IDENTITY FROM JAVA | 65 |
| 10.8-2 | SETTING SYSTEM IDENTITY FROM CONSOLE | 65 |
| 10.8-3 | SYSTEM IDENTITY PARAMETERS | 65 |
| 10.9 | SYSTEM DATE AND TIME..... | 65 |
| 10.9-1 | SETTING DATE AND TIME FROM JAVA | 65 |
| 10.9-2 | SETTING DATE AND TIME FROM CONSOLE | 65 |
| 10.9-3 | DATE AND TIME PARAMETERS | 66 |
| 10.10 | SYSTEM LOGS MANAGEMENT | 66 |
| 10.10-1 | MANAGING SYSTEM LOGS FROM JAVA..... | 66 |
| 10.10-2 | MANAGING SYSTEM LOGS FROM CONSOLE | 66 |
| 10.10-3 | SYSTEM LOGS PARAMETERS | 67 |
| 10.11 | LICENSE | 68 |

11 TOOLS69

| | | |
|-------------|---|-----------|
| 11.1 | PING..... | 69 |
| 11.1-1 | LAUNCHING PING UTILITY FROM JAVA | 69 |
| 11.1-2 | LAUNCHING PING UTILITY FROM CONSOLE..... | 69 |
| 11.1-3 | PING UTILITY PARAMETER DESCRIPTION | 69 |
| 11.2 | TRACEROUTE..... | 70 |
| 11.2-1 | LAUNCHING TRACEROUTE UTILITY FROM JAVA..... | 70 |
| 11.2-2 | LAUNCHING TRACEROUTE UTILITY FROM CONSOLE | 70 |
| 11.2-3 | GENERAL TRACEROUTE UTILITY PARAMETERS..... | 70 |
| 11.3 | BANDWIDTH TEST..... | 70 |
| 11.3-1 | TEST BANDWIDTH FROM JAVA | 71 |
| 11.3-2 | TEST BANDWIDTH FROM CONSOLE | 71 |
| 11.3-3 | BANDWIDTH TEST PARAMETERS | 71 |
| 11.4 | PING FLOOD..... | 72 |
| 11.4-1 | LAUNCHING PING FLOOD FROM JAVA | 72 |
| 11.4-2 | LAUNCHING PING FLOOD FROM CONSOLE..... | 72 |
| 11.4-3 | PING FLOOD UTILITY PARAMETERS: | 72 |

Preface

Document Organization

The document consists of 11 main parts. Parts can be divided further into sections. Each section (or a part if it doesn't consist of sections) of this document is divided into three subsections. In the first subsection management from the Java Console is described. Management from the Console is described in the second subsection. The third subsection is devoted to description of the parameters. However some sections are not divided if it is not necessary.

Document Conventions

In this publication, the following conventions are used:

- All console related settings: commands, arguments, parameters, examples and keywords are marked out with the `Courier New` font;
- The following conventions are used in the command syntax description:
 - In the place where something is written in between of “<” and “>” you need to enter a value, e.g. `<address>`;
 - Optional parameters are enclosed in brackets, e.g. `[interface <name>];`
 - The vertical line “|” means “OR”;

1. Startup Guide

1-1 Before You Start

To make a PC based router running MikroTik™ Router Software, it is necessary to:

- Prepare the PC hardware to be dedicated router – no other programs can be held on the HDD or run on the PC except the MikroTik™ Router Software
- Prepare to obtain an installation archive from “Mikrotiks” SIA – the file is approximately 5.5MB
- Prepare four 3.5” 1.44 MB blank, formatted floppy disks. Make sure that they are not write – protected or damaged. Disks will be used to make four installation floppy disks from the installation archive for installing the PC router software.

After the preparations have been done

- Download the installation archive from www.mikrotik.com. The standard MikroTik™ Router Software installation is distributed as self – extracting archive.
- Run the archive file on a Win95/98/NT computer, and press the ‘Setup’ button to automatically launch the “MikroTik™ Disk Maker”. Follow the screen instructions to create four installation floppy disks. Insert the disks in the FDD as prompted. Put a label on each disk to avoid later confusion. When the “MT Disk Maker” ends its work, you will have a set of MikroTik™ Router Software installation disks ready.
- Install the MikroTik™ Router Software using the four installation floppy disks as described below.
- Obtain the license for your installation of the MikroTik™ Router Software.

1-2 Hardware Requirements and BIOS Settings

The MikroTik™ Router Software installs on a standard PC system with a hard disk or flash disk. Hardware requirements are as follows:

Processor – DX486 or higher CPU with math co-processor. Pentium (AMD, Cyrix, IDT WinChip or Intel) 100 or higher suggested;

RAM – at least 16 MB;

Video – Color or Monochrome VGA video card or on-board VGA port;

HDD controller – IDE hard drive controller;

HDD – Hard disk or flash disk (20 MB or more);

FDD – 1,44 MB Floppy Drive. This is not needed after installation, and can be safely removed;

Keyboard – may be also removed after the software installation, if BIOS allows the PC to boot without a keyboard.

Monitor – may be removed after installation. You should keep the keyboard and monitor attached if you want to administer the system locally from the console.

Network Interface – NE2000 or compatible NIC. For more supported network cards and devices, please see 'Supported Hardware' section.

Check the BIOS settings of your router. Make sure that the boot sequence is 'A: C:', and 'Floppy drive seek at boot' is enabled.

Check that the BIOS settings for PNP OS are disabled and PCI and ISA allocation of IRQs correspond to your interface installation plans. Disable the parallel port to free resources. Check the IO and IRQ assignments for Serial Interfaces, which should be as follows:

COM1 – IO 0x3f8 and IRQ 4
COM2 – IO 0x2f8 and IRQ 3

If you use 20MB SanDisk 3.5" FlashDrive as the target HDD for your router installation, use the recommended BIOS settings for it:

Cylinders 612, Heads 2, Sectors 32, Mode NORMAL

1-3 Installing the software

Put 'Disk #1' in the floppy drive, and boot up your router. The installation will be looking for hard drives. You will see something like this:

```
Found harddrive on IDE primary master (disk C)
To install software properly, it needs to be reformatted.
```

```
Format it? [y/n]:
```

Press yes to format you HDD.

Note that the primary hard disk of your router will be overwritten, and any existing data on it will be destroyed.

You will be asked to insert all next three installation floppies:

```
Please insert 2nd installation floppy.
Press ENTER when ready
```

and so on until the last floppy drive will be inserted and you will be asked to reboot your computer:

```
Software installed.
Press ENTER to reboot
```

Remove the installation disk from the floppy disk drive and press ENTER.

While booting up the router for the first time you will see your software ID, and you will be asked to enter your software key. This key is unique depending on several variables including the particular data carrier (flash disk or hard drive) and information from your MikroTik registered account. Please enter the software key obtained from MikroTik – www.mikrotik.com.

The software installation is complete.

Log on to your PC router running MikroTik™ Router Software for the first time using login name 'root' and password 'root'. Please change the root's password later for security reasons to avoid unauthorized access to your router.

NOTE: There is no way to replace a lost password, so be careful!

1-4 Configuring the Router

A connection via console port is established using an RS-232 null modem cable. Standard PCs have a 9 pin male serial port built-in. Use any VT100 terminal emulation program on your PC or Laptop. The required communication settings are:

9600 bps, 8 bit, No parity, 1 stop bit

For PC with Windows running, set the COM port to your corresponding serial port. Usually it is COM2.

After logging on to your PC router, you should go to the "interface" submenu to see the installed interfaces. Use the following command for that:

```
interface> print
```

If the device driver for the installed network interface card is loaded automatically (for example, most PCI NIC's), the interface should already be listed. Select the desired interface and type and enable it:

```
interface>set up <interface name>
```

If the device driver could not be loaded automatically, load the driver for the installed NIC using the "driver" submenu. Use the load command and supply the required parameters. For example, a NE2000 ISA card configured to use IO 0x300 and IRQ 5 requires following line to be entered:

```
driver>load name ne2k-isa io 0x300
```

Do not forget to enable the interface from the "interface" submenu as described above!

Go to the "ip address" submenu to assign an IP address to the router, for example:

```
ip address>add local 192.168.0.2 mask 255.255.255.224  
interface ether1
```

(If not supplied, the network prefix 192.168.0.0 and broadcast address 192.168.0.31 will be calculated automatically in this case.)

Last thing to configure, before the router can be accessed remotely, is default gateway. Go to the 'Routes' menu and enter

```
ip route>add gateway 192.168.0.1 interface ether1
```

This will add the default route, i.e., to the destination 0.0.0.0 with network mask 0.0.0.0, using host 192.168.0.1 as a gateway, which can be reached using interface ether1.

Try to ping some host on your network to test the initial configuration, for example:

```
ip route>/ping 192.168.0.1
```

If you get responses from the host, your network connection works properly, and you should be able to access the router remotely via network.

Please read appropriate sections of this manual for more detailed description of configuration options.

2 User Interconnection Description

2.1 Java Interconnection Description

MikroTik Java Console requires Java 2 browser plug-in.

In the Web Browser open the page with the address `http://<IPAddressOfTheRouter>`. Then start the applet.

2.1-1 General Information

When you type your login name and password you are logged in the router via Java Console.

All operations are performed via the main menu that is situated on the left of the main window. It consists of ten items. If menu item has an arrow sign than it contains submenu. Each of them is described in the User Manual in the corresponding chapter, excluding "Help". The table below describes the correlation.

| Menu item | Chapter Name |
|------------|------------------------------|
| Interfaces | Network Interface Management |
| IP | Internet Protocol Management |
| Routing | Advanced Routing Management |
| Queues | Queues Management |
| Bridge | Bridge Configuration |
| Drivers | Device Driver Management |
| SNMP | SNMP Service Configuration |
| System | System Configuration |
| Tools | Tools |
| Password | System Configuration |


2.1-2 How To

Here are the most common actions that you perform on the entries:

| Action | Description |
|--------|---|
| Open | To open the required window simply click on the corresponding menu item. |
| Add | To add a new entry you should click on the "+" icon in the corresponding window. |
| Remove | To remove an existing entry click on the "-" icon. |
| Edit | There can edit an existing entry in two ways. The first one is to click twice on the icon on the left of each line. Then in the appeared window you can edit the required parameters. Click |


| | |
|---------|--|
| | <p>“OK” to accept changes or “Cancel” to discard them. The other way is to edit entry parameters directly in the mail window where all the entries are displayed. To accept your changes click on the appeared “Star Sign” in the right column and choose “Accept”. If you want to discard the changes that has been made choose “Cancel”.</p> |
| Refresh | Click on the “Refresh” icon in the corresponding window. |
| Undo | Click on the “Undo” icon above the main menu. |
| Redo | Click on the “Redo” icon above the main menu. |
| Logout | Click on the “Logout” icon above the main menu. |

Main Menu



Editing an Entry

If you have edited entry parameters directly in the list box then you have to accept or discard your changes by clicking on the appeared star sign.



2.2 Console Interconnection Description

When you log in the router via console or telnet you get in the base level. As it is in Java almost every command has the corresponding chapter in the Manual. In the table below base level commands are described:

| Command Name | Description | Chapter in the Manual |
|--------------|-----------------------------------|---------------------------------------|
| ping | Send ICMP Echo packets | Tools |
| floodping | Launch Flood Ping utility | Tools |
| import | Run exported configuration script | |
| telnet | Run Telnet | |
| quit | Quit Console | |
| setup | Do basic setup of the system | Terminal Setup and Basic System Setup |
| password | Change user password | System Configuration |
| undo | Undo previous action | |
| redo | Redo previously undone action | |
| export | Export the router configuration | |
| traceroute | Trace route to host | Tools |

| | | |
|------------|-----------------------------------|---------------------------------------|
| btest | Run bandwidth test to remote host | Tools |
| interface/ | Interface configuration | Network Interface Management |
| driver/ | Driver management | Device Driver Management |
| sys/ | | System Configuration |
| bridge/ | | Bridge Configuration |
| snmp/ | SNMP configuration | SNMP Service Configuration |
| terminal/ | Set terminal type | Terminal Setup and Basic System Setup |
| ip/ | IPv4 specific settings | Internet Protocol Management |
| routing/ | Routing protocol settings | Advanced Routing Management |

The slash in the end of the command means that this command leads to the submenu.

2.2-1 How To

The table below describes how you can execute commands, move through the levels in the console, etc.

| Command | Action |
|----------------------|---|
| command [Enter] | Execute the command |
| [?] | Show the list of all available commands |
| command [?] | Display help on the command and the list of arguments |
| command argument [?] | Display help on the command's a |
| [Tab] | Complete the command/word. If the input is ambiguous, a second [Tab] gives possible options |
| / | Move up to the base level |
| /command | Execute the base level command |
| .. | Move up one level |
| " " | Enter an empty string |
| "word1 word2" | Enter space between words |

You can abbreviate names of levels, commands and arguments.

2.2-2 Import and Export

There is a possibility to export/import router configuration to/from the files, i.e. to create a new file or to add chosen configuration to an existing file either to import configuration from a file to the router. These files are stored in the ftp access area of the router. That is where you can get by connecting to the router via ftp using login and password of the user `root`.

Command `export` has the following parameters:

| Parameter Name | Description |
|-------------------------------|---|
| <code><filename></code> | Export configuration to the file with this name |
| <code>append</code> | Append configuration to a specified file |

Command `import` has only one parameter:

| Parameter Name | Description |
|-------------------------------|--|
| <code><filename></code> | Import router configuration from a specified file. File is taken from router ftp access area |

Command `export` can be found in every level of the command tree. By executing it you can export the configuration of a specified level. For example if you execute this command in “`ip address`” level you will get the information about IP addresses settings. But if you execute it in “`ip`” level you will get the information about all IP settings: NAT, Firewall, DHCP, etc.

To view the configuration as it will look like in the export file simply enter the command `export` without any parameter.

For example you want to make a file that consists of Firewall settings and NAT settings. The file name is `test`. Then you have to execute the following commands:

```
[MikroTik]> ip firewall export test
[MikroTik]> ip nat export test append
```

The file can be accessed now by ftp (only user `root` can do that). Also these configurations are ready to be imported any time:

```
[MikroTik]> import test
```


3 Device Driver Management

Device drivers represent the software interface part of installed network devices. For example, the **MikroTik** system includes device drivers for NE2000 compatible Ethernet cards and other network devices. If you need a device driver for a device, which is not on the list, please suggest it at our suggestion page on our website.

Most device drivers are loaded automatically. For instructions on specific device drivers see the chart below.

Unloading of device driver is useful when changing network devices – this can be useful in avoiding loading drivers for devices, which have been removed from the system. This may be done automatically by removing the card and rebooting before inserting the new network device. The device drivers can be removed only if the appropriate interface has been disabled first.

3-1 Managing Device Drivers from Java

Select the “Drivers” menu to display the currently installed drivers. New drivers can be installed by selecting the “+”. Existing drivers can be removed by selecting the “-” as long as their status is ‘disabled’ (set in the Interface menu). PCI drivers cannot be removed.

3-2 Managing Device Drivers from Console

Driver management commands are located in the “driver” menu.

| Command syntax | Description |
|--|---------------------|
| load <driver name> [irq <IRQ>] [io <IO range start>] [mem <shared memory>] | Load driver |
| unload <number> | Unload driver |
| print | Show loaded drivers |

Where <number> is number of a loaded driver, which can be viewed in the list, generated by the “print” command.

3-3 Device Driver Parameters

| Name in console | Name in JAVA | Description |
|-----------------|--------------|---|
| name | Driver | Name of driver to install* |
| irq | IRQ | Interrupt Request Number. Can be omitted if device does not use IRQ. For IRQ probing enter 0 in Java Box. |

| | | |
|-----|-----|---|
| io | IO | Input/Output port range base address. Can be omitted if device does not use IO ports. If you want to enter I/O port range base address in hexadecimal form, you should put "0x" before it, e.g. 0x300 |
| mem | MEM | Shared Memory base address. Can be omitted if device does not use Shared Memory. |

*- In console use abbreviated form of driver name, available from help.

3-4Supported interfaces

PCI Cards

Driver name: ne2k-pci

Interfaces: RealTek RTL-8029
Winbond 89C940
Compex RL2000
KTI ET32P2
NetVin NV5000SC
Via 86C926
SureCom NE34
Winbond
Holtek HT80232
Holtek HT80229

Driver name: 3c95x (3Com 3c590/3c900 series Vortex/Boomerang driver)

This device driver is designed for the 3Com FastEtherLink and FastEtherLink XL, 3Com's PCI to 10/100baseT adapters. It also works with the 10Mbps versions of the FastEtherLink cards. The supported product IDs are shown in the following table:

Interfaces: 3c590, 3c592, 3c595, 3c597, 3c900, 3c905
3c590 Vortex 10Mbps
3c595 Vortex 100baseTx
3c595 Vortex 100baseT4
3c595 Vortex 100base-MII
3Com Vortex
3c900 Boomerang 10baseT
3c900 Boomerang 10Mbps Combo
3c900 Cyclone 10Mbps Combo
3c900B-FL Cyclone 10base-FL
3c905 Boomerang 100baseTx
3c905 Boomerang 100baseT4

3c905B Cyclone 100baseTx
3c905B Cyclone 10/100/BNC
3c905B-FX Cyclone 100baseFx
3c905C Tornado
3c980 Cyclone
3cSOHO100-TX Hurricane
3c555 Laptop Hurricane
3c575 Boomerang CardBus
3CCFE575 Cyclone CardBus
3CCFE656 Cyclone CardBus
3c575 series CardBus (unknown version)
3Com Boomerang (unknown version)

Driver name: lmc

Interfaces: LanMedia LMC5200
LanMedia LMC5245
LanMedia LMC1000

Driver name: eeepro100 (Intel i82557/i82558 PCI EtherExpressPro driver)

This device driver is designed for the Intel i82557 "Speedo3" chip, Intel's single-chip fast Ethernet controller for PCI, as used on the IntelEtherExpressPro 100 adapter.

Driver name: tulip

This device driver is designed for the DECchip "Tulip", Digital's single-chip ethernet controllers for PCI. Supported members of the family are the 21040, 21041, 21140, 21140A, 21142, and 21143. Similar work-alike chips from Lite-On, Macronix, ASIX, Compex and other listed below are also supported.

Interfaces: Digital DC21040 Tulip
Digital DC21041 Tulip
Digital DS21140 Tulip
Digital DS21143 Tulip
Lite-On 82c168 PNIC
Macronix 98713 PMAC
Macronix 98715 PMAC
Macronix 98725 PMAC
ASIX AX88140
Lite-On LC82C115 PNIC-II
ADMtek AN981 Comet
Compex RL100-TX
Intel 21145 Tulip
Xircom Tulip clone

Driver name: rtl8139

This device driver is designed for the RealTek RTL8129, the RealTek Fast Ethernet controllers for PCI. This chip is used on a few clone boards.

Interfaces: RealTek RTL8129 Fast Ethernet
RealTek RTL8139 Fast Ethernet
SMC1211TX EZCard 10/100 (RealTek RTL8139)
Accton MPX5030 (RealTek RTL8139)

Driver name: winbond-840

This driver is for the Winbond w89c840 chip.

Interfaces: Winbond W89c840
Compex RL100-ATX

ISA Cards

Driver name: ne2k-pci

Interface: NE2000

4 Network Interface Management

4.1 Introduction

An Interface is physical or virtual device which provides a connection to an external network. Network interfaces are created automatically when the Network Interface Card driver is loaded. Virtual (software) interfaces can be created manually.

4.1-1 Managing Network Interfaces from Java

Select the “Interfaces” menu to open the interface list window. The interfaces list displays basic interface parameters. Interface type specific parameters can be changed from interface details windows (opened by double clicking on icon to the left from interface name). The Interface details window has a standard “Traffic” tab which displays traffic that enters and leaves router through the interface. It can also contain other tabs with interface type specific parameters.

The Interfaces list window also contains a “blink” button. Selecting this button causes traffic to be generated on the highlighted interface and therefore blink the LEDs (light emitting diodes) on the card so that an administrator can determine which Interface name corresponds to the actual interface (when there are multiple interfaces of the same type). Note that not all interfaces support this function.

4.1-2 Managing Network Interfaces from Console

Network interface commands and submenus are located in “interface” menu. It contains several commands that are common to all interfaces:

| Command syntax | Description |
|--|-----------------------------------|
| <code>print</code> | Show interface summary |
| <code>set <interface> [up] [down] [name <new name>] [mtu <MTU>]</code> | Change basic interface properties |
| <code>traffic <interface></code> | Monitor traffic on interface |

Where <interface> is interface name or number obtained from “print” command.

The “interface” menu also contains device type specific submenus with device type specific commands. The following device type submenus can be available, depending on what features are licensed for a particular installation:

| Submenu | Description |
|----------|-------------------------------|
| ether | Ethernet interfaces |
| lmc | LMC Sync interfaces |
| ppp | Async PPP interfaces |
| ipsec | IPSec tunnels |
| radiolan | RadioLAN interfaces |
| arlan | Arlan IC2200 interfaces |
| sync | Moxa Sync interfaces |
| pc | Aironet 35/45/4800 interfaces |
| wavelan | WaveLAN interfaces |

4.1-3 Basic Interface Parameter Description

| Name in console | Name in Java | Description |
|-----------------|---------------|--|
| name | Name | Human friendly name for the interface. Maximum 31 character. |
| up | Enabled (yes) | Enable interface |
| down | Enabled (no) | Disable interface |
| mtu | MTU | Maximum Transfer Unit (in bytes) |
| | Enabled | Enable or disable interface |

4.2 Ethernet Interfaces

Ethernet interfaces include standard 10/100 Mbit Ethernet network interface. Ethernet interfaces do not have any device type dependent parameters. Each Ethernet interface has its MAC-address (Media Access Control).

4.2-1 Managing Ethernet Interfaces from Java

Ethernet interface parameters can be changed from interface list window or from interface details window “General” tab.

4.2-2 Managing Ethernet Interfaces from Console

Ethernet interface management is done in submenu “interface ether”.

| Command syntax | Description |
|--|--------------------------------|
| print [<interface>] | Show interface(s) information |
| set <interface> [up] [down] [name <new name>] [mtu <MTU>] | Change interface properties |
| blink <interface> | Generate traffic to blink LEDs |

Where <interface> is interface name or number obtained from “print” command.

4.3 Arlan IC2200 Interfaces

Arlan IC2200 interfaces include Aironet's Arlan IC2200 (655) 2.4GHz 2Mbps ISA Client Cards.

4.3-1 Managing Arlan IC2200 Interfaces from Java

Arlan IC2200 specific parameters can be controlled from the "Radio" tab in interface details window. Current status (registration status and registered router and backbone) can be monitored in real time on "Status" tab in interface details window.

4.3-2 Managing Arlan IC2200 Interfaces from Console

Arlan IC2200 interface management is done in the submenu "interface arlan".

| Command syntax | Description |
|--|---------------------------------------|
| <code>print [<interface>]</code> | Show interface(s) information |
| <code>set <interface> [up] [down] [name <new name>] [mtu <MTU>] [frequency <channel frequency>] [bitrate <bitrate>] [cardname <card name>] [arlan <yes no>] [sid <SID>]</code> | Change interface properties |
| <code>monitor <interface></code> | Monitor interface status in real time |
| <code>blink <interface></code> | Generate traffic to blink LEDs |

Where <interface> is interface name or number obtained from "print" command.

Interface status includes registration status and registered router and backbone.

4.3-3 Arlan IC2200 Parameter Description

| Name in console | Name in Java | Description |
|-----------------|--------------|---|
| frequency | Frequency | Channel frequency in MHz. |
| bitrate | Bitrate | Data Transmission speed in Mbits |
| cardname | Card Name | Name of the client to be shown in the registration table of the Access Point or |

| | | |
|-------|----------|--|
| | | Bridge. Maximum 15 characters. |
| sid | SID | Value of System Identifier. Should be the same for all nodes on the radio network. Maximum 31 character. |
| arlan | TMA mode | Enable/Disable registration mode when client has to register to an AP2000 Access Point or BR2000-E Bridge. |

4.4 LMC Sync Interfaces

LMC Sync interfaces include LMC5200 (HSSI), LMC5245 (DS3) and LMC1000 (V.53) cards.

4.4-1 Managing LMC Sync Interfaces from Java

LMC interface specific parameters can be controlled from the “Advanced” tab in the interface details window. Current status (status of card LEDs and current clock speed) can be monitored in real time on “Status” tab in interface details window.

4.4-2 Managing LMC Sync Interfaces from Console

LMC Sync interface management is done in submenu “`interface lmc`”. It contains commands:

| Command syntax | Description |
|--|---------------------------------------|
| <code>print [<interface>]</code> | Show interface(s) information |
| <code>set <interface> [up] [down] [name <new name>] [mtu <MTU>] [extclk <yes no>] [scrambler <yes no>] [longcable <yes no>]</code> | Change interface properties |
| <code>monitor <interface></code> | Monitor interface status in real time |

Where `<interface>` is interface name or number obtained from “`print`” command.

Interface status includes status of card LEDs and current clock speed.

4.4-3 LMC Sync Interface Parameter Description

| Name in console | Name in Java | Description |
|------------------------|----------------|--------------------------------------|
| <code>extclk</code> | External Clock | Enable/Disable use of external clock |
| <code>scrambler</code> | DS3 Scrambler | Enable/Disable DS3 Scrambler |

| | | |
|-----------|----------------|-------------------------------|
| longcable | Long DS3 Cable | Enable/Disable long DS3 cable |
|-----------|----------------|-------------------------------|

4.5 PPP Interfaces

PPP (or Point-to-Point Protocol) provides a method for transmitting datagrams over serial point-to-point links. The 'com1' and 'com2' ports from standard PC hardware configurations will appear as 'serial0' and 'serial1' automatically. It is possible to add thirty-two additional serial ports with the Moxa C168 PCI multiport asynchronous card (eight ports each) to use the router for a modem pool.

4.5-1 Managing PPP Interfaces from Java

PPP interface specific parameters can be controlled from the "PPP" tab in the interface details window. Depending on line operation mode (dial-in, dial-out, or direct) additional parameters can be controlled from the "In" (for dial-in mode) or "Out" (for dial-out mode) tab. Current status (current line status, error description, uptime, and name of logged in user) can be monitored in real time under the "Status" tab in interface details window.

Note: The standard serial ports have a default configuration as serial "console" ports – see the 'Parameters' section for details.

4.5-2 Managing PPP Interfaces from Console

PPP interface management is done in the submenu "interface ppp".

| Command syntax | Description |
|---|---------------------------------------|
| print [<interface>] | Show interface(s) information |
| set <interface> [up] [down] [name <new name>] [mtu <MTU>] [mru <MRU>] [type <dial-in dial-out direct>] [auth <none pap chap>] [user <username>] [server <servername>] [line <linespeed>] [phone <phonenumber>] [tone <on off>] [rings <rings>] [nullmodem <on off>] [demand <on off>] [idle <idletime>] [init <string>] [defaultroute no off on yes] | Change interface properties |
| monitor <interface> | Monitor interface status in real time |

Where <interface> is interface name or number obtained from “print” command.

Interface status includes current line status, error description (if any), uptime and name of logged in user.

4.5-3 PPP Interface Parameters

| Name in console | Name in Java | Description |
|-----------------|-------------------|--|
| mru | MRU | Maximum Size of received packets |
| type | (type selection) | Line operation mode. Default value is Dial-In |
| auth | Authentication | Authentication type for this port |
| user | User Name | User name to use to log into server when dialing out. Can contain letters, digits, “*” and “_” |
| server | Server Name | Server name of this port for dial-in. Can contain letters, digits, “*” and “_” |
| line | Line Speed | Speed of serial line |
| phone | Phone Number | Phone number to call when dialing out |
| tone | Tone Dial | Enable/Disable tone dial |
| rings | Rings | Number of rings to wait before answering phone |
| nullmodem | Null Modem | Enable/Disable null-modem mode (when enabled, no modem initialization strings are sent). Default value is “on”. So by default null-modem is turned on. |
| demand | Dial On Demand | Enable/Disable dial on demand |
| idle | Idle Time | Idle time after which close connection |
| init | Modem Init | Modem Initialization String |
| defaultroute | Add Default Route | Add PPP remote address as a default route. Other settings are: destination=0.0.0.0 netmask=0.0.0.0 interface=ppp, preferred source=0.0.0.0 |

4.6 IPSec Tunnels

IPSec tunnels are virtual interfaces that encrypt all traffic that is sent over them and forwards them as IP packets to tunnel endpoint. IPSec tunnels can be created and removed manually. A router can have total of 16 IPSec tunnels.

4.6-1 Managing IPSec Tunnels from Java

IPSec specific parameters can be controlled from the “IPsec” tab in interface details window. New IPSec tunnels can be created by selecting the “Add” button in interface list window. IPSec interfaces can be removed by selecting the “Remove” [-] button in interface list window.

4.6-2 Managing IPSec Tunnels from Console

IPSec tunnel management is done in the submenu “interface ipsec”.

| Command syntax | Description |
|---|---------------------------------------|
| <code>print [<interface>]</code> | Show interface(s) information |
| <code>add <interface> [up] [down] [name <new name>] [mtu <MTU>] remote <remote IP> spibase <spibase> mode <MD5-3DES MD5-DES> ahkey <ahkey> espkey <espkey> [myside <left right>]</code> | Add IPSec tunnel |
| <code>set <interface> [up] [down] [name <new name>] [mtu <MTU>] [remote <remote IP>] [spibase <spibase>] [mode <MD5-3DES MD5-DES>] [ahkey <ahkey>] [espkey <espkey>] [myside <left right>]</code> | Change interface properties |
| <code>monitor <interface></code> | Monitor interface status in real time |
| <code>remove <interface></code> | Remove IPSec tunnel |

Where <interface> is interface name or number obtained from “print” command.

Interface status includes registration status and registered router and backbone.

4.6-3 IPSec Tunnel Parameters

| Name in console | Name in Java | Description |
|----------------------|-----------------|---|
| <code>remote</code> | Remote Address | IP address of remote endpoint of tunnel |
| <code>spibase</code> | SPI Base | SPI Base |
| <code>mode</code> | Encryption mode | Encryption mode to use to encrypt packets |
| <code>ahkey</code> | AH Key | Authentication Header Key |
| <code>espkey</code> | ESP Key | ESP Key |
| <code>myside</code> | Side | Side of tunnel. Must be different for each end of tunnel. |

4.7 RadioLAN Interfaces

RadioLAN interface supports the RadioLAN ISA CardLINK – Model 101 10Mbit radio card.

4.7-1 Managing RadioLAN Interfaces from Java

RadioLAN specific parameters can be controlled from the “Radio” tab in interface details window. Current status (current default destination) can be monitored in real time on “Status” tab in interface details window.

RadioLAN interfaces have an additional capability of low level radio connection testing. Test can be started and results monitored in real time on under the “Ping” tab.

4.7-2 Managing RadioLAN Interfaces from Console

RadioLAN interface management is done in submenu “interface radiolan”.

| Command syntax | Description |
|--|---------------------------------------|
| print [<interface>] | Show interface(s) information |
| set <interface> [up] [down] [name <new name>] [mtu <MTU>] [distance <distance>] [txdiv <on off>][rxdiv <on off>][mode <alone ap cfg firstap firstclient>] [maxretr <maxretries>] [sid <SID>] [clientname <clientname>] [cfgdst <destination>] | Change interface properties |
| monitor <interface> | Monitor interface status in real time |
| table <interface> | Show neighbor table |
| test <interface> address <MAC address> [total <total>] [size <size>] | Test link to remote RadioLAN host |
| blink <interface> | Generate traffic to blink LEDs |

Where <interface> is an interface name or number obtained from “print” command. Interface status includes current default destination.

4.7-3 RadioLAN Interface Parameters

| Name in console | Name in Java | Description |
|-----------------|------------------------------|---|
| distance | Distance | Distance to remote end of point to point link |
| txdiv | Tx Diversity | Enable/Disable transmit diversity |
| rxdiv | Rx Diversity | Enable/Disable receive diversity |
| mode | Default destination | Operation mode |
| maxretr | Maximum Retries | Maximum retries to use when sending |
| sid | SID | System Identifier (4 chars max) |
| clientname | Name | Client name string. 15 characters maximum. |
| cfgdst | (Default destination string) | Configured destination. Used only in operation mode when default destination is configured. |

Test utility parameters:

| Name in console | Name in Java | Description |
|-----------------|--------------|--|
| address | Ping To | MAC address of host to test link to |
| total | Packets | Total number of packets to use in test |
| size | Packet Size | Size of test packets |

4.8 Moxa Sync Interfaces

Moxa Sync interfaces supports the Moxa C101 Sync adapters.

4.8-1 Managing Moxa Sync Interfaces from Java

Moxa Sync specific parameters can be controlled from “Synchronous” tab in interface details window. Current status (status of modem control lines, time since last keepalive and sequence number difference) can be monitored in real time under the “Status” tab in interface details window.

4.8-2 Managing Moxa Sync Interfaces from Console

Moxa Sync interface management is done in submenu “`interface sync`”.

| Command syntax | Description |
|--|-------------------------------|
| <code>print [<interface>]</code> | Show interface(s) information |
| <code>set <interface> [up] [down] [name <new name>] [mtu <MTU>] [keepalive <keepalive>] [speed <speed>]</code> | Change interface properties |

| | |
|---|---------------------------------------|
| [rxclock <internal line>] [txclock <internal line rx>] [nullmodem <on off>] | |
| monitor <interface> | Monitor interface status in real time |
| blink <interface> | Generate traffic to blink LEDs |

Where <interface> is an interface name or number obtained from “print” command.

Interface status includes status of modem control lines (DTR, RTS, CTS, DSR, DCD), time since last keepalive, and sequence number difference.

4.8-3 Moxa Sync Interface Parameters

| Name in console | Name in Java | Description |
|-----------------|-----------------|---|
| keepalive | Keepalive | Interval after which keepalive is sent (in seconds) |
| speed | Speed | Speed of internal clock |
| rxclock | Rx Clock Source | Receive clock source |
| txclock | Tx Clock Source | Transmit clock source |
| nullmodem | Null Modem | Enable/Disable null-modem mode (ignore DCD signal) |

4.9 Aironet 35/45/4800 Interfaces

Aironet 35/45/4800 interfaces include Aironet 3500, 4500, and 4800 ISA and PCI adapters. If you have an ISA adapter, than make sure to configure DIP switches correctly.

Configuring DIP Switches (ISA Only)

The Aironet ISA adapter contains DIP switches for setting Plug and Play Mode (PnP), Base Address, and Interrupt Levels (IRQ). The switches are set for PnP mode by default.

Devices cannot share the same Base address or IRQ. Check the switch settings on the adapter to ensure the do not conflict with other devices in the computer.

PnP mode is controlled by the 6th switch:

| | |
|----------------------------|-----------|
| 6 th DIP Switch | |
| On (Non-PnP) | Off (PnP) |

If you set PnP mode on then all other settings are not taken into account. If you still want to use PnP mode make sure that the default IRQ and Base Address do not conflict with the other devices. The default are:

| Base Address | IRQ Level |
|--------------|-----------|
| 140 | 5 |

If you want to configure other IRQ and Base Address values, make sure PnP mode is turned off, i.e. 6th switch is On.

4.9-1 Managing Aironet 35/45/4800 Interfaces from Java

Aironet 35/45/4800 specific parameters can be controlled from “General”, “RF Network,” and “Advanced” tabs in interface details window. Current status (current signal quality, channel frequency, synchronization and association status, name of Access Point, and MAC address of Access Point) can be monitored in real time under the “Status” tab in interface details window.

4.9-2 Managing Aironet 35/45/4800 Interfaces from Console

Aironet 35/45/4800 interface management is done in the submenu “interface pc”.

| Command syntax | Description |
|--|---------------------------------------|
| <code>print [<interface>]</code> | Show interface(s) information |
| <code>set <interface> [up] [down]</code> <code>[name <new name>] [mtu <MTU>]</code> <code>[type <ad-hoc infrastructure>]</code> <code>[rtsthres <RTSthres>]</code> <code>[fragthres <fragthres>]</code> <code>[txpower <power>]</code> <code>[rxdiv <default both left right>]</code> <code>[txdiv <default both left right>]</code> <code>[longretr <longretr>]</code> <code>[shortretr <shortretr>]</code> <code>[channel <channel>] [rate <rate>]</code> <code>[ap1 <AP1>] [ap2 <AP2>] [ap3 <AP3>]</code> <code>[ap1 <AP4>] [ssid1 <ssid1>]</code> <code>[ssid2 <ssid2>] [ssid3 <ssid3>]</code> <code>[modulation <CCK MBOK default>]</code> <code>[clientname <client name>]</code> <code>[bperiod <bperiod>]</code> | Change interface properties |
| <code>monitor <interface></code> | Monitor interface status in real time |

Where <interface> is interface name or number obtained from “print” command.

Interface status includes current signal quality, channel frequency, synchronization, association, name of Access Point, and MAC address of Access Point.

4.9-3 Aironet 35/45/4800 Interface Parameters

| Name in console | Name in Java | Description |
|-----------------|-------------------------|--|
| type | Infrastructure Mode | Operation mode of card (ad hoc or infrastructure). Default value is "infrastructure" |
| rtsthres | RTS threshold | RTS Threshold |
| fragthres | Fragmentation threshold | Fragmentation threshold |
| power | Transmit Power | Transmit power |
| rxdiv | Receive Antenna | Receive diversity |
| txdiv | Transmit Antenna | Transmit diversity |
| longretr | Long Retries | Long retry limit |
| shortretr | Short Retries | Short retry limit |
| channel | Channel | Channel frequency |
| rate | Data Rate | Data rate |
| ap1 | Access Point 1 | Access Point 1 (MAC Address) |
| ap2 | Access Point 1 | Access Point 2 (MAC Address) |
| ap3 | Access Point 1 | Access Point 3 (MAC Address) |
| ap4 | Access Point 1 | Access Point 4 (MAC Address) |
| ssid1 | SSID1 | Service Set Identifier 1 |
| ssid2 | SSID2 | Service Set Identifier 2 |
| ssid3 | SSID3 | Service Set Identifier 3 |
| modulation | Modulation | Modulation mode |
| clientname | Client name | Client name |
| bperiod | Beacon period | Beacon period |

Read the User Guide for details how to connect to the Access Point.

4.10 WaveLAN Interfaces Base Configuration

WaveLAN interfaces support 802.11 standard, i.e. it works with Aironet access points and works at 11Mbps rate. Tx power: 35 mW.

This interfaces needs the same license, as for Aironet 4800 interfaces. The driver is loaded automatically, when you boot up the router with the PCMCIA WaveLAN Network Adapter.

4.10-1 Managing WaveLAN Interfaces from Console

WaveLAN interface management is done in the submenu “interface wavelan”.

| Command syntax | Description |
|---|---------------------------------------|
| print [<interface>] | Show interface(s) information |
| set <interface> [up] [down] [nick <new nickname>] [mtu <MTU>] [mode <ad-hoc infrastructure>] [rts <RTSthres>] [frag <fragthres>] [txpower <power>] [freq <frequency>] [rate <rate>] [essid <essid>] | Change interface properties |
| export | |
| blink | |
| monitor <interface> | Monitor interface status in real time |

Where <interface> is interface name or number obtained from “print” command.

4.10-2 WaveLAN Interface Parameters

| Name in console | Name in Java | Description |
|-----------------|-------------------------|---|
| mode | Infrastructure Mode | Operation mode of card (ad hoc or infrastructure). Default value is “infrastructure” |
| rts | RTS threshold | RTS Threshold. Value can be from 0 till 2347 |
| frag | Fragmentation threshold | Fragmentation threshold. Values can be from 256 till 2346 |
| freq | Frequency | Frequency for a network in Ad-Hoc mode. |
| rate | Data Rate | Data rate. Can be 1, 2, 5.5, 11 or auto. |
| essid | SSID | Network name. You should write in Access Point ssid. If not define, can connect to any AP |
| nick | Nickname | Card nickname |

5 Bridge Configuration

Bridging is used to pass MAC layer packets between interfaces without any routing. When the routers are used in bridging mode, Spanning Tree Protocol is used to avoid bridging loops and to communicate information between routers/bridges. Bridging works only for Ethernet and RadioLan interfaces. You can bridge between Ethernet and RadioLan networks, only the router should be a default destination (on MAC level) for others clients of the radio network. Also you can bridge Ethernet networks through RadioLan network (point-to-point).

5-1 Configuring Bridge from Java

Select the Bridge menu. Various protocols can be enabled or disabled.

5-2 Configuring Bridge from Console

Bridge configuration commands are located in “bridge” menu.

| Command syntax | Description |
|---|-----------------------------|
| Print | Show bridge configuration |
| set [bridge <on off>] [ip <on off>] [ipx <on off>] [ipv6 <on off>] [atalk <on off>] | Change bridge configuration |

5-3 Bridge Configuration Parameters

| Name in console | Name in Java | Description |
|-----------------|--------------|---|
| bridge | Enabled | Enable/disable bridge |
| ip | IP | Enable/disable bridging of IP protocol |
| ipx | IPX | Enable/disable bridging of IPX protocol |
| ipv6 | IPv6 | Enable/disable bridging of IPv6 protocol |
| atalk | AppleTalk | Enable/disable bridging of AppleTalk protocol |

6 Internet Protocol Management

The Internet Protocol Management section includes configuration of all IP level settings such as IP addresses, DHCP, static routes, and so on.

6.1 Addresses

Addresses serve as identification when communicating with other network devices. It is possible to add multiple IP addresses to each of the interfaces or to leave interfaces without addresses assigned to them.

6.1-1 Managing Addresses from Java

Select the IP/Addresses menu. The “Addresses List” list shows all IP addresses with basic settings. From the “Address List” window addresses can be edited, added, and removed. Some addresses (when using PPP) can appear and disappear dynamically. Dynamic addresses are marked with blue icon, others with yellow. Inactive addresses (their interfaces are disabled) are shown in gray and italic.

6.1-2 Managing Addresses from Console

Select “address” in the “ip” menu.

| Command syntax | Description |
|--|---------------------------|
| add local <address> [prefix <prefix>] mask <mask> [broad <address>] interface <name> | Add new address |
| set <number> [local <address>] [prefix <prefix>] [mask <mask>] [broad <address>] [interface <name>] | Change address properties |
| remove <number> | Remove address |
| print | Show addresses |
| export | Export addresses |

6.1-3 General Address Parameters

| Name in Console | Name in Java | Description |
|-----------------|-------------------|--|
| interface | Interface | Name of interface the address will be used with |
| local | Local Address | Local IP address for the interface. |
| mask | Network Mask | Network Mask to be used with the prefix. |
| prefix | Prefix | (optional) Network Prefix to be used with the address. It shows what network can be reached through the interface with the given IP address. If not specified, will be calculated from Local Address and Network Mask. |
| broad | Broadcast Address | (optional) Broadcast Address to be used with the address. If not specified, will be calculated from Local Address and Network Mask. |

6.2 Routes

Routes are needed for communicating with networks that are not directly attainable via the router's local interfaces. Routes to locally connected interfaces and networks are created automatically based on the IP address assigned to local interfaces. Static routes, including the default route, are set in the IP/Routes menu. Other automatic routes are created by routing daemons, such as RIP and OSPF, which can be found in the Routing menu from the base level. Dynamic routes are shown in IP/Routes, too.

6.2-1 Managing Routes from Java

Select the "Routes" menu under the "IP" menu. The "Routes List" shows current routes settings which can be edited, added, and deleted. Disabled routes (interface they are using is disabled) are shown in gray and italic. Dynamic routes are marked with blue icon, others with red.

6.2-2 Managing Routes from Console

Select th submenu "ip route".

| Command syntax | Description |
|---|---------------|
| add interface <name> [gw <address>] [dst<address>] [mask <mask>] | Add new route |

| | |
|---|-------------------------|
| [prefsrc <address>] | |
| set <number> [dst <address>] [mask <mask>] [gw <address>] [prefsrc <address>] [interface <name>] | Change route properties |
| Remove <number> | Remove route |
| print | Show routes |
| export | Export routes |

6.2-3 General Routes Parameters

| Name in console | Name in Java | Description |
|-----------------|--------------|--|
| dst | Dst. Address | Destination IP address of a host or network |
| mask | Netmask | Network Mask of the destination |
| gw | Gateway | Next gateway to the destination |
| interface | Interface | Interface to be used |
| prefsrc | Pref. Source | (optional) Source Address of packets leaving the router via this route |

6.3 ARP

ARP (Address Resolution Protocol) displays IP addresses and respective MAC addresses of interfaces which are physically connected to local interface. The ARP table entries appear automatically as it sends broadcast messages to all interfaces physically connected to the local interfaces. It is possible to manually assign static ARP entries.

6.3-1 Managing ARP from Java

Select the 'ARP' menu under the 'IP' menu. The 'ARP List' displays IP addresses, MAC addresses, and interface names and allows to edit, add, and remove ARP entries. Inactive entries are shown in gray color and italic font. Permanent entries are marked with red icon.

6.3-2 Managing ARP from Console

Select the located in "address" menu that is in the "ip" menu.

| Command syntax | Description |
|--|----------------------|
| add interface <name> ip <address> mac <address> | Add static ARP entry |
| set <number> | Change ARP entry |

| | |
|---|--------------------|
| [interface <name>] [ip <address>][mac <address>] | |
| remove <number> | Remove ARP entry |
| print | Show ARP entries |
| export | Export ARP entries |

6.3-3 General ARP Parameters

| Name in console | Name in Java | Description |
|-----------------|------------------|----------------|
| ip | IP Address | IP address |
| mac | Hardware Address | MAC address |
| interface | Interface | Interface name |

6.4 PPP

Here you can setup PPP IP related settings: addresses, RADIUS and DNS which will be imparted to PPP clients.

6.4-1 Managing PPP from Java

Select the IP/Addresses menu. The “PPP IP Settings” list allows configuration of local address and remote address. To edit DNS and RADIUS server settings, select the details box located next to the refresh icon.

6.4-2 Managing PPP from Console

Management of PPP is done in the “ip ppp”. The following commands can be executed there:

| Command syntax | Description |
|--|----------------------------|
| print | Show interfaces |
| dns | PPP DNS settings menu |
| radius | PPP RADIUS settings menu |
| set <interface> [local <address>] [remote <address>] | Change IP address settings |
| export | Export IP address settings |

“ip ppp dns” menu commands:

| Command syntax | Description |
|--|---|
| export | Export PPP DNS settings |
| print | Show PPP DNS settings |
| set [primary <address>] [secondary <address>] | Set primary and secondary Domain Name Servers |

“ip ppp radius” menu commands:

| Command syntax | Description |
|---|------------------------|
| export | Export RADIUS settings |
| print | Show RADIUS settings |
| set [radius no off on yes] [server <address>] [secret <string>] [accounting no off on yes] | Change RADIUS settings |

6.4-3 General PPP Parameters

| Name in console | Name in Java | Description |
|-----------------|----------------------|----------------------------------|
| interface | Interface | Interface name |
| local | Local Address | Local IP address |
| remote | Remote Address | Remote IP address |
| primary | Primary DNS Server | Primary DNS server address |
| secondary | Secondary DNS Server | Secondary DNS server address |
| radius | Use RADIUS | Enable/disable RADIUS server |
| server | RADIUS Server | RADIUS server address |
| secret | Shared Secret | Shared secret |
| accounting | RADIUS Accounting | Enable/disable RADIUS accounting |

6.5 DHCP

DHCP is Dynamic Host Configuration Protocol. DHCP's purpose is to enable individual computers on an IP network to extract their configurations from a server (the 'DHCP server') or servers, in particular, servers that have no exact information about the individual computers until they request the information. The overall purpose of this is to reduce the work necessary to administer a large IP network.

6.5-1 Managing DHCP from Java

Select the “DHCP” menu under the ”IP” menu.

6.5-2 Managing DHCP from Console

DHCP management can be controlled from the “dhcp” menu under the “ip” menu. The “dhcp” menu “lease” option shows all current DHCP leases.

“ip dhcp” menu commands:

| Command syntax | Description |
|--|-------------------------------|
| lease | DHCP leases menu |
| print | Show DHCP interfaces |
| export | Export DHCP settings |
| set <interface> [dhcp on off] [from <address>] [to <address>] [lease <hh:mm:ss>] [srcaddr <address>] [mask <mask>][gateway <gateway>] [domain <name>] [dns <address>] | Set DHCP interface properties |

“ip dhcp lease” menu commands:

| Command syntax | Description |
|----------------|--------------------------|
| print | Show current DHCP leases |

6.5-3 General DHCP Parameters

| Name in console | Name in Java | Description |
|-----------------|-----------------------|--|
| interface | Interface | Interface name |
| dhcp | Enabled | Enable/disable DHCP |
| from to | Address From To | The range of IP addresses that can be given to the clients. |
| lease | Lease Time | Time in hh:mm:ss the lease will be given out. |
| srcaddr | Src. Address | Source address of the router's DHCP interface to be used by the client when contacting the router. |
| mask | Netmask | Network mask to be used with the IP address. |
| gateway | Gateway | Default gateway to be used by the client. |
| domain | Domain Name | Domain name assigned to the client. |

| | | |
|-----|--------------------|---|
| dns | DNS Server Address | DNS server address to be used by the client for address resolution. |
|-----|--------------------|---|

Lease parameters (read only):

| Name in console | Name in Java | Description |
|-----------------|--------------|---|
| Interface | Interface | Interface name |
| IP address | IP Address | Client IP address |
| MAC address | Hw. Address | Client MAC address |
| Lease time | Lease Time | Lease time. Value should be hh:mm:ss, where hh is hours, mm is minutes and ss is seconds. |

6.6 Firewall

Firewall supports filtering and security functions that are used to manage data flows to the router and through it. Along with the Network Address Translation they serve as security tools for preventing unauthorized access to networks.

Filtering rules organized together in chains do packet filtering. Each chain can be considered as a set of rules. There are three default chains, which cannot be deleted. More chains can be added for grouping together filtering rules. When processing a chain, rules are taken from the chain in the order they are listed from the top to the bottom.

Packets entering the router through one of the interfaces are first matched against the filtering rules of the Input chain. If the packet is not dropped or rejected, and it is for the router itself, the packet is delivered locally. If the packet is not dropped or rejected, but it has to be delivered outside the router, then the packet is processed according to the routing table. If the processing is successful, then the packet is matched to the filtering rules of the forward chain. After that, packet is passed to the output interface and processed according to the rules of output chain.

Packets originated from the router are processed according to the output chain only.

The firewall also has a packet “mark” feature which is used to mark packet flows for the standard queuing process and bandwidth allocation.

6.6-1 Managing Firewall Functions from Java

Select the “Firewall” menu under the “IP” menu. Select the corresponding tag to enter/edit desired information.

6.6-2 Managing Firewall Functions from Console

Firewall management can be performed from the “ip firewall” menu.

| Command syntax | Description |
|----------------|---------------------------|
| chain | Firewall chains menu |
| rule | Firewall chain rules menu |
| export | Export firewall settings |

“ip firewall chain” menu commands:

| Command syntax | Description |
|--|-----------------|
| print | Show all chains |
| add [name <name>] [policy accept deny masquerade reject] | Add new chain |
| set <chain name or number> [name <name>] [policy <policy>] | Change chain |
| remove <chain name or number> | Remove chain |

“ip firewall rule” menu commands:

| Command syntax | Description |
|---|--------------|
| add <chain> [action accept deny jump masq none reject return] [proto <protocol>] [target <chain>] [srcaddr <address>] [srcmask <mask>] [srcports <ports>] [dstaddr <address>] [dstmask <mask>] [dstports <ports>] [interface <name>] [tcp all nosys sys] [flow <mark>] [log on off] | Add new rule |
| set <chain> <rule number> [action accept deny jump masq none reject return] [proto <protocol>] [target <chain>] | Change rule |

| | |
|--|--|
| <pre>[srcaddr <address>] [srcmask <mask>][srcports <ports>] [dstaddr <address>] [dstmask <mask>] [dstports <ports>] [interface <name> all] [tcp all nosys sys][flow <mark>] [log on off]</pre> | |
| <pre>remove <chain name or number> <rule number></pre> | Remove rule |
| <pre>move <chain> <source> <destination></pre> | Move rule in this chain from source number to destination number |
| <pre>print <chain name or number></pre> | Show rules |

6.6-3 General Firewall Parameters

Rule parameters:

| Name in console | Name in Java | Description |
|--------------------------------|--|--|
| action | Action | Action to perform |
| log | Log | Turns on or off logs writing option. |
| srcaddr srcmask srcports | Source Address Mask Port | Source address, mask, and port of the packet. Default port 0 means all ports 1-65535. For ICMP packets, port parameter means ICMP packet type. |
| dstaddr dstmask dstports | Destination Address Mask Port | Destination address, mask, and port of the packet Default port 0 means all ports 1-65535. For ICMP packets, port parameter means ICMP packet code. |
| proto | Protocol | Protocol name of the packet: all, icmp, tcp, udp etc. |
| interface | Interface | Interface name or all for any interface |
| tcp | TCP Options | Can be specified only if tcp is selected. |
| target | Target Chain | Can be specified if action is 'jump' |
| flow | Flow Mark | Mark for the packet to be used in further actions (queuing). Flow mark is used only inside the router, and it is lost when the packet exits the router. If there are several rules for marking the packet, the packet is marked with the flow mark from the last applied rule. |

Actions to perform on rules:

| Action name in console | Action name in Java | Description |
|------------------------|---------------------|--|
| accept | Accept | Accept everything |
| reject | Reject | Reject everything and send ICMP reject message |
| deny | Deny | Silently drop the packet (without sending the ICMP reject message) |
| masq | Masq | Use masquerading |
| return | Return | Return to the chain from which this rule has been invoked |
| jump | Jump | Jump to another chain |

Chain parameters:

| Name in console | Name in Java | Description |
|-----------------|--------------|--------------|
| name | Name | Chain name |
| policy | Policy | Chain policy |

6.7 NAT

NAT (Network Address Translation) is the translation of an IP address used within one network to a different IP address known within another network. One network is designated the *inside* network and the other is the *outside*. Typically, an administrator maps the local inside network addresses to one or more global outside IP addresses and unmaps the global IP addresses on incoming packets back into local IP addresses. This helps ensure security since each outgoing or incoming request must go through a translation process that also offers the opportunity to qualify or authenticate the request or match it to a previous request. NAT also conserves the number of global IP addresses and it lets the whole network use a single IP address in its communication with the world.

6.7-1 Managing NAT from Java

Select the “NAT” menu under the “IP”. The “NAT” list allows editing, adding, and removing NAT entries.

6.7-2 Managing NAT from Console

Network Address Translation management is performed in the “ip nat” menu.

| Command syntax | Description |
|---|--|
| <code>print</code> | Show NAT rules |
| <code>export</code> | Export NAT rules |
| <code>move <source number> <destination number></code> | Move NAT rule from source number to destination number |
| <code>remove <rule number></code> | Remove NAT rule |
| <code>add [interface <name>] [scr <address>] [smask <mask>] [dst <address>] [dmask <mask>] [rotocol <protocol>] [spots <port range>] [dports <port range>] [nat-src <address>] [nat-dst <address>] [nat-smask <mask>] [nat-dmask <mask>] [nat-sport <potr>] [nat-dport <port>] [translate on off] [direction in out]</code> | Add NAT rule |
| <code>set <number> [interface <name>] [scr <address>] [smask <mask>] [dst <address>] [dmask <mask>] [rotocol <protocol>] [spots <port range>] [dports <port range>][nat-src address>] [nat-dst <address>] [nat-smask <mask>] [nat-dmask <mask>] [nat-sport <potr>] [nat-dport <port>] [translate on off] [direction in out]</code> | Change NAT rule |

6.7-3 General NAT Parameters

| Name in console | Name in Java | Description |
|---------------------------------------|-----------------------------------|---|
| <code>direction in out</code> | Direction | The direction of the packet, where <code>in</code> means from the interface into the router, and <code>out</code> means from the router to the interface. |
| <code>src smask sports</code> | Source Addr: Mask: Port: | Source address, mask, and port of the packet (default port 0 means all ports 1-65535) |
| <code>dst dmask dports</code> | Destination Addr: Mask: | Destination address, mask, and port of the packet (default port 0 means all ports 1-65535) |

| | | |
|-----------------------------------|--|---|
| | Port: | |
| interface | Interface | Name of the interface the packet is passing through |
| protocol | Protocol | Protocol name of the packet: all, icmp, tcp, etc. |
| translate | Translate | Designates the action to perform on packet – translate or leave unchanged |
| nat-src nat-smask nat-sport | Source Addr: Mask: Port: | New source address, mask, and port of the packet (port 0 and address 0.0.0.0 mean: leave unchanged) |
| nat-dst nat-dmask nat-dport | Destination Addr: Mask: Port: | New destination address, mask, and port of the packet (port 0 and address 0.0.0.0 mean: leave unchanged) |

6.8 DNS

By using a DNS server, router administrators can use hostnames instead of IP addresses when setting up routes, filters, and other places where a numbered IP address is not required.

6.8-1 Managing DNS from Java

Select the “DNS” menu under the “IP” menu. The “DNS” box can be configured with the primary DNS and secondary DNS by selecting the DNS settings icon.

6.8-2 Managing DNS from Console

“ip dns” menu commands:

| Command syntax | Description |
|--|--------------------------------------|
| export | Export DNS configuration and entries |
| static | Static DNS entries management menu |
| set [primary <address>] [secondary <address>] | Change DNS settings |
| print | Show DNS settings |

“ip dns static” menu commands:

| Command syntax | Description |
|--|---------------------------|
| print | Show static DNS entries |
| export | Export static DNS entries |
| add name <hostname> address <address> | Add static DNS entry |
| remove <entry number> | Remove static DNS entry |
| set <number> [name <hostname>] [address <address>] | Change static DNS entry |

6.8-3 General DNS Parameters

| Name in console | Name in Java | Description |
|-----------------|----------------------|------------------------------|
| name | Name | Host name |
| address | IP Address | Host IP address |
| primary | Primary DNS Server | Primary DNS server address |
| secondary | Secondary DNS Server | Secondary DNS server address |

7 SNMP Service Configuration

The **MikroTik** router currently supports a limited implementation of the SNMP protocol. Currently SNMP can only be used to remotely monitor the network and collect statistics. The current **MikroTik** SNMP agent provides information about traffic on network interfaces and system information (name, location, contact, routes, addresses, interfaces, ARPs, and TCP connections). **MikroTik** router has only one community (others are not supported) of the type “public” and it is read-only. I.e. the router cannot be configured using SNMP management programs. It is possible only to set location and contact information parameters from the Console or the Java Console.

7-1 Configuring SNMP from Java

Select the SNMP menu to enabled or disabled and set SNMP service information.

7-2 Configuring SNMP from Console

SNMP configuration commands are located in “routing/snmp” menu. It contains following commands:

| Command syntax | Description |
|--|-----------------------------------|
| print | Show SNMP service configuration |
| set [status <on off>] [location <router location>] [contact <contact information>] | Change SNMP service configuration |

7-3 SNMP Configuration Parameters

| Name in console | Name in Java | Description |
|-----------------|--------------|---|
| status | Enabled | Enable/disable SNMP service |
| location | Location | Router location. Maximum 255 characters |
| contact | Contact Info | Administrator contact information. Maximum 255 characters |

8 Queues Management

Queuing is a mechanism that controls bandwidth allocation, delay variability, timely delivery, and delivery reliability.

8-1 Managing Queuing from Java

Open the “Queues” window by clicking on the corresponding menu. New queues are automatically added when an interface is inserted and set up. When a queue is set to type “split”, new sub-node queues can be added. Each new queue can be set to queuing type (or algorithm).

8-2 Managing Queuing from Console

Not supported.

| Command syntax | Description |
|----------------|-------------|
| | |

8-3 General Queuing Parameters

Queue parameters:

| Name in Console | Parameter | Description |
|-----------------|------------|---|
| | Queue type | Available queue types |
| | Flow mark | Flow mark of the stream (sorting parameter). See <i>Firewall</i> section. |
| | Limited at | Maximum bandwidth for the stream |
| | Priority | Flow priority (1..15) |
| | Weight | Flow weight |
| | Allocated | The number of bytes allocated for the bandwidth |
| | Isolated | Other queues wont be able take over this queue bandwidth |
| | Bounded | The queue can occupy other queues if its necessary |

| Queue type | Characteristics |
|------------|--|
| PFIFO | Packet First-In First-Out – is the simplest queuing algorithm. The packets are served in the same order as they are received |
| BFIFO | The same as PFIFO, except that this algorithm is byte-based but not packet-based |
| RED | Random Early Detection – an algorithm for congestion avoidance in packet-switched networks |
| Split | This type allows the packets to be sorted by flow mark and specify the parameters for each such sub-node separately. Each sub-node can be of type PFIFO or BFIFO. It cannot be split further |

RED queue parameters:

| Name in console | Name in Java | Description |
|-----------------|---------------|--|
| | Queue Type | Queue type |
| | Bandwidth | Queue bandwidth (in bytes/sec) |
| | Min Threshold | Before this value is achieved no packets will be thrown away |
| | Max Threshold | When this value is achieved the queue will throw away the packets using maximum probability, where this probability is a function of the average queue size ¹ . |
| | Queue Size | Queue size in bytes |
| | Burst | Number of packets allowed for an occasional bursts of packets in the queue |

PFIFO queue parameters:

| Name in console | Name in Java | Description |
|-----------------|-------------------------|---|
| | Queue Type | Queue type |
| | Bandwidth | Queue bandwidth (in bytes/sec) |
| | Queue Size (in packets) | Maximum packet number that queue can hold |

¹ If probability is denoted by **p** then consider the following: **min** <= **p** <= **max**, where **min** is **p** when *average queue size = minimum queue size (p=0%)* and **min** is **p**, when *average queue size = maximum queue size (p=2%)*.

BFIFO queue parameters:

| Name in console | Name in Java | Description |
|-----------------|--------------------------|---|
| | Queue Type | Queue type |
| | Bandwidth | Queue bandwidth (in bytes/sec) |
| | Queue Size (in bytes) | Maximum byte number that queue can hold |

9 Advanced Routing Management

Standard kernel routes are created when adding an address to the router and static routes are added by the user. A third type of route is created by software daemons such as GateD routing. For exchanging the routing information between the routers, MikroTik™ Router Software supports two interior routing protocols: the Routing Information Protocol (RIP) [Version 1 and Version 2] and the Open Shortest Path First (OSPF) protocol.

9.1 Routing Information Protocol

RIP selects the route with the lowest metric as the best route. The metric is a hop count representing the number of gateways through which data must pass through to reach its destination. To enable the exchange of routing information between two routers connected to the same network both routers should have RIP enabled on the interfaces to the network which connects them. Only information about kernel routes and routes learned using RIP is exchanged between the routers.

9.1-1 Managing RIP from Java

Select the “Routing” menu and the “RIP” menu. Select the icon of the desired interface to change its RIP settings.

9.1-2 Managing RIP from Console

Go to the “routing” menu by executing the command with the corresponding name from the base level. Then go to the “rip” menu.

| Command syntax | Description |
|---|---------------------|
| <code>print</code> | Show RIP settings |
| <code>export</code> | Export RIP settings |
| <code>set <interface> [in none rip1-2] [out none rip1 rip1- comp rip2] [auth MD5 none simple] [metric <value>] [passwd <passwd>]</code> | Change RIP settings |

9.1-3 General RIP Parameters

| Name in console | Name in Java | Description |
|-----------------|----------------|--|
| interface | Interface | Interface name |
| in | In | Incoming RIP mode |
| out | Out | Outgoing RIP mode |
| auth | Authentication | Authentication mode |
| passwd | Password | Password string |
| metric | Metric | Metric used both outgoing and incoming routes (this metric is added to existing metric of route). Positive numbers greater than 0. |

9.2 Open Shortest Path First

OSPF is a shortest path first or link-state protocol. OSPF is an interior gateway protocol that distributes routing information between routers in a single autonomous system. OSPF chooses the least cost path as the best path. OSPF is better suited than RIP for complex networks with many routers. OSPF provides equal cost multipath routing where packets to a single destination can be sent via more than one interface simultaneously.

9.2-1 Managing OSPF from Java

Select the “Routing” menu and then the “OSPF” menu. Four tabs can be used for configuration: “Interfaces”, “Areas”, “Stub Hosts,” and “Virtual Links”.

9.2-2 Managing OSPF from Console

Go to the “routing ospf” menu.

| Command syntax | Description |
|------------------------|--|
| interface | OSPF interfaces menu |
| area | OSPF areas menu |
| shost | OSPF stub hosts menu |
| vlink | OSPF virtual links menu |
| set routerid <address> | Change router ID (if this value is not set than the router will choose any of assigned IP addresses) |
| print | Show router ID |
| export | Export OSPF settings |

OSPF interfaces menu commands:

| Command syntax | Description |
|---|---|
| print [detail] | Show OSPF interfaces (you can use detailed form) |
| export [<filename> append] | Export OSPF interface settings (You can export in a file or append to an existing file) |
| set <interface> [up] [down] [area <name>] [cost <value>] [prio <value>] [passwd <password>] [retr <value>] [delay <value>] [hello <value>] [dead <value>] | Change OSPF interface settings |

OSPF areas menu commands:

| Command syntax | Description |
|---|-------------------|
| print | Show OSPF areas |
| export [<filename> append] | Export OSPF areas |
| set <area> [name <name>] [cost <value>] [auth none simple] [stub on off] | Change OSPF areas |
| add name <name> id <address> [cost <value>] [auth none simple>] [stub on off] | Add new OSPF area |
| remove <area name or number> | Remove area |

OSPF stub hosts menu commands:

| Command syntax | Description |
|--|-----------------------------|
| print | Show OSPF hosts |
| export [<filename> append] | Export OSPF hosts |
| set <host> [area <name>] [cost <value>] [host <address>] | Change stub host properties |
| add area <name> cost <value> host <address> | Add stub host |
| remove <host number> | Remove stub host |

OSPF virtual links menu commands:

| Command syntax | Description |
|--|---|
| print [detail] | Show virtual links (you can do it in detailed form) |
| export [<filename> append] | Export OSPF virtual links |
| set | Change virtual link properties |
| add area <name> neighbor <address> [prio <value>] [passwd <password>] [retr <value>] [delay <value>] [hello <value>] [dead <value>] | Add virtual link |
| remove <link number> | Remove virtual link |

9.2-3 General OSPF Parameters

Interfaces parameters:

| Name in console | Name in Java | Description |
|-----------------|----------------------|--|
| interface | Interface | Interface name |
| area | Area | Area |
| up down | Enabled | Enable/Disable OSPF |
| cost | Cost | Cost. Positive number greater than 0 |
| prio | Priority | Priority. Number from 0 till 255 |
| passwd | Password | Password |
| retr | Retransmit Interval | Retransmit Interval. Greater than 0. Default value is 5. |
| delay | Transit Delay | Transit Delay. Greater than 0. Default value is 1. |
| hello | Hello Interval | Hello Interval. Greater than 0. Default value is 10. |
| dead | Router Dead Interval | Router dead interval. If the router doesn't receive an answer from the neighbor router during that time it will regard it as not functioning. Greater than 0. Default value is 40. |

Areas parameters:

| Name in console | Name in Java | Description |
|-----------------|----------------|--------------------------------------|
| name | Area name | Area name |
| id | Area ID | Area ID |
| stub | Stub Area | Area that has only one link outside |
| cost | Cost | Cost. Positive number greater than 0 |
| auth | Authentication | Authentication mode |

Stub hosts parameters:

| Name in console | Name in Java | Description |
|-----------------|--------------|--------------------------------------|
| host | Host | Host address |
| area | Area | Area |
| cost | Cost | Cost. Positive number greater than 0 |

Virtual links parameters:

| Name in console | Name in Java | Description |
|-----------------|----------------------|--|
| neighbor | Neighbor ID | The other end router ID |
| area | Transit Area | Transit Area |
| prio | Priority | Priority. Values from 0 till 255. |
| passwd | Password | Password |
| retr | Retransmit Interval | Retransmit Interval. Greater than 0. Default value is 5. |
| delay | Transit Delay | Transit Delay. Greater than 0. Default value is 1. |
| hello | Hello Interval | Hello Interval. Greater than 0. Default value is 10. |
| dead | Router Dead Interval | Router dead interval. If the router doesn't receive an answer from the neighbor router during that time it will regard it as not functioning. Greater than 0. Default value is 40. |

10 System Configuration

10.1 Terminal Setup and Basic System Setup

10.1-1 Basic System Setup

This action can be performed only in the console. The described below commands can be executed from the base level or from anywhere else if you type “/” before them.

10.1-2 Basic Router Setup

Basic router setup can be done from the base level using setup command.

If you have an NE2000 Ethernet card then it was loaded automatically on boot all you have to do is to enable this interface and make all necessary IP settings. You can do that using the `setup` command:

| Command | Parameters | Description |
|--------------------|-------------------------------|-------------------------------------|
| <code>setup</code> | | Basic system setup |
| | <code>Enable interface</code> | Enable an interface |
| | <code>IP Address</code> | Set router's IP address |
| | <code>Netmask</code> | Set network mask |
| | <code>Gateway</code> | Set a default gateway of the router |

Try to ping some host on your network to test the initial configuration, for example:

```
[MikroTik]> ping 1.1.1.2
```

If you get responses from the host, your network connection works properly, and you should be able to access the router remotely via network.

If you have some other network card please read the “Device Driver Management” section in the User Manual for details on a specific driver you are using, whether it is loaded automatically or not. If it was loaded automatically then the `setup` command would work as described above.

If the driver was not loaded automatically then the `setup` command will ask you to do that. Also you will be prompted to enter IP parameters:

| Command | Parameters | Description |
|---------|-------------|--|
| setup | | Basic system setup |
| | Load driver | Load network device driver. You can choose one of the following: arlan, moxa, ne2k-isa, pc-isa, radiolan |
| | driver io | Set input/output port range base address. Can be omitted if device does not use IO ports |
| | driver irq | Set Interrupt Request Number. Can be omitted if device does not use IRQ. For IRQ probing enter 0 |
| | IP Address | Set router's IP address |
| | Netmask | Set network mask |
| | Gateway | Set a default gateway of the router |

Use ping command as described above to check your settings.

10.1-3 Set Terminal Type

| Command syntax | Description |
|--|------------------------------|
| set [ansi linux rxvt-m vt100 vt220 xterm dumb rxvt sun vt102 vt52] | Set terminal type |
| print | Show current terminal type |
| reset | Reset previous terminal type |

10.2 Packages

Packages are used to upgrade the router or add features. Packages should be obtained from the Mikrotik website. Packages can be FTPed to the router only by user "root". After rebooting the router, the packages will be installed.

10.2-1 Viewing Packages from Java

Select the "System" menu and then the "Packages" menu. Name, version, and build numbers of the installed packages are shown under the "Installed" tab. Name, version, and upload time are shown of the uploaded packages under the "Uploaded" tab.

10.2-2 Viewing Packages from Console

In the console installed and uploaded packages information can be viewed in the “sys package” menu by executing the following command:

| Command syntax | Description |
|----------------|-------------------------|
| installed | Installed packages menu |
| uploaded | Uploaded packages menu |

“sys package installed” menu commands:

| Command syntax | Description |
|---|-------------------------|
| set <number> [uninstall no off yes on] | Uninstall package |
| print | Show installed packages |

“sys package uploaded” menu commands:

| Command syntax | Description |
|-----------------|----------------------------|
| remove <number> | Remove an uploaded package |
| print | Show uploaded packages |

10.2-3 Packages Parameters

Installed packages parameters:

| Name in console | Name in Java | Description |
|-----------------|--------------|----------------------------------|
| name | Name | Name of the package |
| version | Version | Version number of the package |
| build | Build Number | Build Number |
| uninstall | Uninstall | Will uninstall after next reboot |

Uploaded packages parameters:

| Name in console | Name in Java | Description |
|-----------------|--------------|-------------------------------|
| name | Name | Name of the package |
| version | Version | Version number of the package |
| build | Build Number | Build Number |

10.3 System History

The system keeps a history of the configuration changes since last boot. The history is lost when the router is rebooted. The 'history' buttons on the Java panel allow the user to 'undo' and 'redo' actions.

10.3-1 Viewing System History from Java

Select the "History" menu. The system history can be viewed in the appeared "History" window. The information is read only. Use the buttons on the main widow to 'undo' and 'redo' actions.

10.3-2 Viewing System History from Console

The system history can be viewed from the "`sys history`" menu.

| Command syntax | Description |
|--------------------|----------------------|
| <code>print</code> | Show command history |

10.3-3 System History Parameters

| Name in console | Name in Java | Description |
|--------------------------|--------------|--|
| <code>description</code> | History | System history |
| <code>level</code> | Access Level | Shows what privileges user privileges are needed to undo the changes |

10.4 User Management

User management includes adding users, removing users, setting names, groups, and passwords.

10.4-1 User Management from Java

User management can be performed from the "Users List" windows that appears after you select the "Users" menu in the "Sys" menu.

10.4-2 User Management from Console

Go to the “sys user” menu.

| Command syntax | Description |
|---|------------------------|
| add name <name> password <password> group full ppp read write [ppp on off] [desc <description>] [server <name>] [addr <address>] | Add new user |
| set <user number> [name <name>] [desc <description>] [ppp on off>] [group full ppp read write>] [password <password>] [addr <address>] [server <name>] | Change user properties |
| remove <user number> | Remove user |
| print | Show user(s) |
| export | Export PPP users |

10.4-3 User Parameters

| Name in console | Name in Java | Description |
|-----------------|------------------|--|
| name | Name | Login name - this value cannot be changed for existing users. Can contain letters, digits, “*” and “_” |
| group | Group | Indicates the access group the user belongs to. See the table below for available values |
| desc | Description | Description for the user |
| password | Password | List box used to change the password for current user. It conforms to standard Unix characteristics of passwords. Can contain letters, digits, “*” and “_” |
| | Confirm | For password confirmation |
| ppp | Allow to use PPP | Enable to allow dial in use or use the user name and password for authentication at the remote host when dialing out |
| server | Server Name | Authentication Server Name (empty field means any server name) for the PPP- |

| | | |
|------|----------------------|--|
| | | users |
| addr | Preferred IP Address | IP address to be assigned to the user's dial-in client when logged in using PPP. If the remote address is specified in PPP interface settings then this address should match the specified address in order to enable client to log in |

Note: user “*” will be used for PPP as any user

Groups parameters:

| Group name in console | Group name in Java | Description |
|-----------------------|--------------------|--|
| ppp | PPP | Designed for PPP accounts. Provides only PPP access to the router |
| read | Read | Can only view the configuration, but not change it |
| write | Write | The same as “Full”, but without permission to add, delete, or change users |
| full | Full | Full control |

10.5 Change Password

You can easily change password using this special command.

10.5-1 How To Change Password Using Java

In the main menu there is an item “Password”. You will be prompted to enter your old password and enter new password twice. When you logout and login for the next time, you must enter the new password. The old password is lost forever.

10.5-2 How To Change Password Using Console

Go to the base level and execute the following command:

| Command syntax | Description |
|----------------|-----------------------|
| password | Change user password. |

You will be prompted to enter your old password and enter new password twice. When you logout and login for the next time, you must enter the new password. The old password is lost forever.

10.6 System Resources

System's uptime, total memory, HDD/Flash drive size, CPU type, and CPU frequency are displayed.

10.6-1 Viewing System Resources from Java

Select the "System" menu and the "Resources" menu. Java gives you expanded possibilities in viewing the system resources. Under the 'Monitor' tab a window shows the utilization of system's CPU and memory usage in graphical form. Under the 'IRQ' tab, the system's hardware IRQ's and their usage are shown. Under 'IO' tab, the system's IO memory ranges used by various devices are shown.

10.6-2 Viewing System Resources from Console

In the console, system resources can be viewed in the " `sys resource`" menu. There are three submenu there.

| Command syntax | Description |
|-------------------|-------------------------------|
| <code>info</code> | General system information |
| <code>io</code> | I/O port range information |
| <code>irq</code> | Interrupt request information |

Submenu commands:

| Submenu | Command | Description |
|-------------------|--------------------|---------------------------|
| <code>info</code> | <code>print</code> | Show system information |
| <code>io</code> | <code>print</code> | Show I/O port information |
| <code>irq</code> | <code>print</code> | Show IRQ information |

10.6-3 System Resources Parameters

General parameters:

| Name in console | Name in Java | Description |
|---------------------------|--------------|-----------------------------------|
| <code>uptime</code> | Uptime | Time passed from the last restart |
| <code>total memory</code> | Total Memory | RAM the router is using |

| | | |
|----------|---------------|-----------------------------------|
| cpu type | CPU | Central Processing Unit type |
| cpu freq | CPU Frequency | Central Processing Unit frequency |
| hdd size | | Hard Disk Drive capacity |
| hdd free | | Hard Disk Drive free |

IRQ parameters:

| Name in console | Name in Java | Description |
|-----------------|--------------|--------------------------------|
| # | IRQ Number | IRQ Line Number (from 0 to 15) |
| State | Used | Used (yes or no) |
| Owner | Name | Owning device name |

I/O parameters:

| Name in console | Name in Java | Description |
|-----------------|-----------------------|--|
| range | Used IO Memory Ranges | Memory addresses that a device can use to send or receive data |
| owner | Name | Owning device name |

10.7 System Shutdown

System shutdown (halt), reboot, and reset controls. For most systems, it is necessary to wait approximately 30 seconds for a safe power down.

10.7-1 System Shutdown from Java

Select the “System” menu then the “Shutdown” menu. The dialog box will appear asking you whether you want to reboot or shutdown the router. Warning: after entering ‘shutdown,’ it is necessary to manually restart the router.

10.7-2 System Shutdown from Console

The following commands can be executed in the “sys” menu:

| Command syntax | Description |
|----------------|--|
| reboot [-f] | Reboot the system. Use -f argument to suppress confirmation |
| reset | Reset the system. Note: This command deletes all router configuration settings!!!! New ID/PWD are root/root |
| halt [-f] | Halt the system. Use -f argument to suppress confirmation |

10.8 System Identity

Set the identification name of the router.

10.8-1 Setting System Identity from Java

Select “System” menu and then “Identity” and enter the router name.

10.8-2 Setting System Identity from Console

Go to the “sys” menu.

| Command syntax | Description |
|--|---------------------|
| <code>identity set <name></code> | Set system identity |

10.8-3 System Identity Parameters

| Name in console | Name in Java | Description |
|-----------------|--------------|--|
| <name> | Router Name | System identity string is used as human friendly name for router and also in SNMP queries. Maximum is 16 characters. |

10.9 System Date and Time

View and change the system date and time settings.

10.9-1 Setting Date and Time from Java

Select the “System” menu and the “Date & Time” menu. Changes will be discarded when the router is restarted.

10.9-2 Setting Date and Time from Console

In the system console date and time settings can be change in two different menus. These commands can be executed from the “sys date” menu:

| Command syntax | Description |
|----------------------------------|-----------------|
| <code>set time [HH:MM:SS]</code> | Set system time |
| <code>set date</code> | Set system date |

| | |
|-----------------|-----------------------------|
| [month/DD/YYYY] | |
| print | Shows current date and time |

Date and time settings become permanent and effect BIOS settings.

10.9-3 Date and Time Parameters

Date parameters:

| Parameter name | Description |
|----------------|---|
| month | Month should be entered using three first letters of its name |
| day | Day of a month |
| year | Year should be entered using all four digits |

Time parameters:

| Parameter name | Description |
|----------------|-------------|
| hours | Hours |
| minutes | Minutes |
| seconds | Seconds |

10.10 System Logs Management

Various system events and status information can be logged. Logs can be saved in a file on the router or sent to a remote server running a syslog daemon. Mikrotik provides a shareware Windows syslog daemon at www.mikrotik.com.

10.10-1 Managing System Logs from Java

Click on the “System” menu. If you want to view all system logs then go to the “Logs” menu. For configuring logs select the “Log Manager” menu. Select the “Log Default Settings” icon to set number of buffer lines, default IP address, and default port. To configure log sources select the icon of the corresponding line.

10.10-2 Managing System Logs from Console

Local logs can be viewed in the “sys logs” menu:

| Command syntax | Description |
|----------------|--------------------------|
| print | Display local log buffer |

Global logging management is performed in the “`sys logger`” menu.

“`sys logger`” menu commands:

| Command syntax | Description |
|---|-------------------------------------|
| <code>print</code> | Show global logging configuration |
| <code>set [address <address>] [port <number>] [lines <number>]</code> | Change global logging configuration |
| <code>sources/</code> | Log sources configuration menu |

“`sources`” submenu commands:

| Command syntax | Description |
|--|-------------------------------------|
| <code>print</code> | Show configuration of log sources |
| <code>set <number> [type local none remote] [address <address>] [port <number>] [prefix <prefix>] [interval <interval>]</code> | Change configuration of log sources |

10.10-3 System Logs Parameters

Log sources configuration parameters:

| Name in console | Name in Java | Description |
|-----------------------|----------------|---|
| <code>group</code> | Group | (Read-only) Name of the log group |
| <code>type</code> | Logging | Type of logging. |
| <code>prefix</code> | Prefix | Local log prefix is used when local logging is enabled. Each line coming from this source is preceded by a prefix |
| <code>address</code> | Remote Address | Remote log server IP address. Used when logging type is remote. If not set, default log server IP address is used |
| <code>port</code> | Remote Port | Remote log server UDP port. Used when logging type is remote. If not set, default log server UDP port is used |
| <code>interval</code> | Interval | Traffic logs dump interval. Used only for Traffic-Account source. Tells how often traffic logs should be dumped |

Types of logging:

| Type | Description |
|--------|--|
| local | When type "local" is used, logs are stored in local log buffer |
| none | When type "none" is used, logs from this source are discarded |
| remote | When type "remote" is used, logs are sent to remote log server |

Global logging parameters:

| Name in console | Name in Java | Description |
|-----------------|------------------------|---|
| lines | Number of Buffer Lines | Number of lines kept in local buffer. When number of lines in local log buffer is exceeded, lines from the beginning of buffer are deleted. |
| address | Default IP Address | Remote log server IP address. Used when remote logging is enabled but no IP address of the remote server is specified (IP=0.0.0.0) |
| port | Default Remote Port | Remote log server UDP port. Used when remote logging is enabled but no UDP port of the remote server is specified (UDP=0) |

10.11 License

You can view and set Software ID Number by executing command “`license`” in the “`sys`” menu in console.

| Command syntax | Description |
|----------------|-------------------------|
| set <key> | Set software key |
| print | Show software ID number |

11 Tools

MikroTik tools include standard TCP/IP tools such as ping and trace-route and also custom made tools. **MikroTik** custom tools are designed to assist you in verifying the quality of links – stability and bandwidth. If you have any suggestion for improving these tools, please suggest it at our suggestion page on our website.

11.1 Ping

Ping uses Internet Control Message Protocol (ICMP) Echo messages to determine if a remote host is active or inactive and to determine the round-trip delay when communicating with it.

11.1-1 Launching Ping Utility from Java

Select the “Ping” submenu in the “Tools” menu. The Ping utility sends four ping messages and displays them in real time in the Ping list box.

11.1-2 Launching Ping Utility from Console

From local console enter the command `ping` from the base level or `us /ping` from any location in the console.

| Command syntax | Description |
|---|--------------------|
| <code>ping <address> [psize <packet size>] [interval <interval>]</code> | Send ICMP Requests |

Ping utility shows Time To Live value of the received packet (ttl) and Roundtrip time (time) in ms.

The console Ping session may be stopped when the `Ctrl + C` is pressed.

11.1-3 Ping Utility Parameter Description

| Name in console | Name in Java | Description |
|------------------------------|--------------|--|
| <code><address></code> | Address | IP address for the host you want to ping. |
| <code>psize</code> | Packet Size | (optional) Size of each ICMP packet (in bytes). |
| <code>interval</code> | Interval | (optional) Delay between messages (in seconds). Default is 1 second. |

11.2 Traceroute

Traceroute is a TCP/IP protocol-based utility, which allows the user to determine how packets are being routed to a particular host. Traceroute works by increasing the time-to-live value of packets and seeing how far they get until they reach the given destination; thus, a lengthening trail of hosts passed through is built up.

11.2-1 Launching Traceroute Utility from Java

Select the “Traceroute” window in the “Tools” menu. When the trace is complete, the output indicates total number of hops to the host and corresponding TTL values per hop.

11.2-2 Launching Traceroute Utility from Console

Execute the command `traceroute` from the base level:

| Command syntax | Description |
|---|-----------------------|
| <code>traceroute <address> [timeout <timeout>] [psize <psize>]</code> | Trace route to a host |

Traceroute shows the number of hops to the given host address of every passed gateway. Traceroute utility sends packets three times to each passed gateway so it shows three timeout values for each gateway in ms.

11.2-3 General Traceroute Utility Parameters

| Name in console | Name in Java | Description |
|------------------------------|--------------|--|
| <code><address></code> | Trace To | IP address of the host you are tracing route to. |
| <code>timeout</code> | Timeout | (optional) Response waiting timeout, i.e. delay between messages (10..1500, default 64). |
| <code>psize</code> | Packet Size | (optional) Packet size in bytes (1..5, default is 1). |

11.3 Bandwidth Test

The Bandwidth Tester can be used to monitor the throughput to a remote **Mikrotik** router (either wired or wireless) and thereby help to discover network ‘bottlenecks’.

The TCP test uses the standard TCP protocol with acknowledgments and follows the TCP algorithm on how many packets to send according to latency,

dropped packets, and other features in the TCP algorithm. Please review the TCP protocol for details on its internal speed settings and how to analyze its behavior. Statistic for throughput are calculated using the entire size of the TCP packet. As acknowledgments are an internal working of TCP, their size and usage of the link are not included in the throughput statistics. Therefore this statistic is not as reliable as the UDP statistic when estimating throughput.

The UDP tester sends 110% or more packets than currently reported as received on the other side of the link. To see the maximum throughput of a link, the packet size should be set for the maximum MTU allowed by the links – usually this is 1500 bytes. There is no acknowledgment required by UDP, this implementation means that the closest approximation of the throughput can be seen.

11.3-1 Test Bandwidth from Java

Select the “Bandwidth” submenu of the “Tools” menu. Designate the IP address of the host to test and choose the test mode (either TCP or UDP).

For UDP, choose the desired Packet Size in the corresponding edit box. The test output is represented as two graphs showing current speed and the ten-second average.

11.3-2 Test Bandwidth from Console

Use the `btest` command from the base level.

| Command syntax | Description |
|---|--|
| <code>btest <address> [type <type>] psize <psize>]</code> | Run bandwidth test to a remote Mikrotik router |

Example:

```
[P46]> btest 10.0.0.56 type udp psize 50
```

Bandwidth test to 159.148.172.206, protocol UDP, packet size 50

To stop bandwidth test use CTRL + C.

11.3-3 Bandwidth Test Parameters

| Name in console | Name in Java | Description |
|------------------------------|------------------------|--------------------------------|
| <code><address></code> | Test link to | IP address of destination host |
| <code>type</code> | TCP / UDP | Test type can be UDP or TCP |
| <code>psize</code> | Packet Size (UDP only) | Packet size (50 to 1500 bytes) |

11.4 Ping Flood

Ping flood sends ICMP (Internet Control Message Protocol) echo requests to a remote host in the same manner as the ping utility but it sends the next request as soon as it receives a reply.

11.4-1 Launching Ping Flood from Java

Select the “Flood Ping” submenu in “Tools” menu. Flood ping shows sent packets percentage (from the given number), received packages percentage, minimum, average and maximal Roundtrip Time of the packages.

11.4-2 Launching Ping Flood from Console

Command `floodping` should be executed from the base level with the following parameters:

| Command syntax | Description |
|---|-------------------|
| <code>floodping <address></code> <code>[psize <size>]</code> <code>[timeout <time>]</code> <code>[total <number>]</code> | Launch flood ping |

11.4-3 Ping Flood Utility Parameters:

| Name in console | Name in Java | Description |
|------------------------------|-------------------|--|
| <code><address></code> | Ping to | IP address of destination host |
| <code>psize</code> | Packet Size | Size of each ICMP packet (in bytes) |
| <code>total</code> | Number of Packets | Number of ICMP packets |
| <code>timeout</code> | Timeout | Time after which in the packet is considered lost in case of no response (in ms) |